




10.2 永磁变频、主机变频




10.3 工变频切换



10.4 风机变频



10.5 主、风机变频



10.6 软启动

